

REPLACEMENT PARTS LIST


BL-2349	RAIL BODY
BL-3351-C	REAR TIRES
BL-3419	FRONT WHEELS
BL-3463	GEAR HUB (2)
BL-3511-N	REAR HUB (2)
BL-4956-A	RISE HEIGHT POST
BL-5031	CHASSIS
BL-5032	CHASSIS BRACE
BL-5152	FRONT TIRE O-RINGS
BL-5186-B	AXLE HEIGHT ADJUSTERS
BL-5190	WING MOUNTS
BL-5235	STEERING BELLCRANK
BL-5238	FRONT AXLE PLATE
BL-5281	ANGLE BRACKET (4)
BL-5308	STEERING LINKAGE
BL-5351	STEERING BLOCKS
BL-5364	STUB AXLES
BL-5377	KINGPINS
BL-5452	REAR BUSHINGS (2)
BL-5457	FRONT BUSHINGS (4)
BL-5680	60 TOOTH 32 PITCH AXLE GEAR
BL-5747	STEEL AXLE
BL-6505	ENGINE MOUNTS
BL-6505-S	ENGINE MOUNT SPACERS (2)
BL-6506-L	LEFT AXLE MOUNT
BL-6506-R	RIGHT AXLE MOUNT

REPLACEMENT PARTS LIST

BL-6511	THROTTLE PLATE SUPPORTS
BL-6525	BRAKE BAND WITH LINING
BL-6527	THROTTLE OVERRIDE
BL-6528	BRAKE LINING (3)
BL-6531	SUB FRAME
BL-6535	POD PLATE
BL-6536	THROTTLE PLATE
BL-6537	THROTTLE BELLCRANK
BL-6538	REAR MOUNT
BL-6540	1 oz. FUEL TANK

ACCESSORIES

BL-2721-A	WING KIT WITH MOUNTS
BL-5451	BALL BEARING KIT



HARDWARE

BL-5221	E-CLIPS
BL-7010	4-40 x 1/4" FLAT HEAD SCREWS (8)
BL-7011	4-40 x 3/8" FLAT HEAD SCREWS (8)
BL-7026	4-40 x 3/8" CAP SCREWS (6)
BL-7027	4-40 x 1/2" CAP SCREWS (6)
BL-7030-B	5-40 x 3/8" WHEEL SCREWS (8)
BL-7150	4-40 SET SCREWS (8)
BL-7160	10-32 HUB SET SCREWS (6)
BL-7206	5-40 NUTS (8)
BL-7404	1/8" WASHERS (10)

BoLINK R/C Cars, Inc.
 420 Hosea Rd
 Lawrenceville, GA 30045
 (770) 963-0252 FAX (770) 963-7334
 www.bolink.com

BL-1237 NITRO RAIL DRAGSTER